





INSTRUCTIONS FOR USE



1:Insert the adjusted ler in a straight shape Tile gap of 1.5 mm or more than 2 mm



2:90°rotating T-type leveler Fix it at the point of 2 tiles



3:Tighten the adjustment cover clockwise by hand or a wrench to make the weo tiles on the same level



4:Wait 4-6 hours, take out the leveler when the tile glue and not completely solidified



5: Rotate the adjustment cover counterclockwise, and then rotate the T-type leveler by 90° to make it parallel to the tile gap



6: Take out the leveler along the edge of the gap, it can be recycled









